

EN Operating instructions
Last updated: 04.2022



Motor unit for hinged gates

Comfort 530

works with



Table of Contents

1.	General safety instructions	3
1.1	Intended use	3
1.2	Target group	3
1.3	Warranty	3
2.	Product information	4
2.1	Supply package	4
2.2	Technical data	4
2.3	Example application	5
3.	Installation	6
3.1	Preparing for installation	6
3.2	Installation dimensions	7
3.3	Installation of support brackets	8
3.4	Installing the motor unit	9
3.5	Connection to the control unit	10
4.	Operation	10
4.1	Hand transmitter	10
4.2	Emergency operation / Release mechanism	10
5.	Care and cleaning	11
6.	Maintenance	11
6.1	Maintenance work by the operator	11
6.2	Maintenance work by qualified and trained professionals	11
7.	Disassembly	11
8.	Disposal	11
9.	Rectifying faults	11
10.	Appendix	12
10.1	Declaration for the incorporation of a partly completed machine	12

Regarding this document

- Original instruction manual.
- Part of the product.
- Read these instructions carefully before use and keep them in a safe place for future reference.
- Protected by copyright.
- No part of this manual may be reproduced without our prior approval.
- Subject to alterations in the interest of technical progress.
- All dimensions are given in millimetres.
- The drawings are not true to scale.

Meaning of symbols



WARNING!

Safety notice indicating a danger that could result in death or severe injury.



CAUTION!

Safety notice indicating a danger that could result in slight or moderate injuries.



NOTICE

Safety notice indicating a danger that could result in damage to property or in irreparable damage to the product.

Meaning of symbols

- Instruction requiring action
- ✓ Check
- List, itemisation
- Reference to other sections of this document
-  Reference to separate documents that must be observed
-  Factory settings

1. General safety instructions

WARNING!

Failure to comply with the documentation could result in life-threatening danger!

- Be sure to follow all the safety instructions in this document.

1.1 Intended use

- The motor unit is designed exclusively for opening and closing hinged gates.
- Never use the gate to lift persons or objects.

The following applies for the product Comfort 530:

- The following values must be observed:
 - maximum tensile force
 - maximum compressive force
 - maximum gate size
 - maximum gate weight

→ „2.2 Technical data“

- The product is intended for private use.
- This product is only suitable for hinged gates.
- The motor unit requires a suitable control unit.

1.2 Target group

- Installation, connection, setting in operation and servicing: qualified and trained specialist personnel.
- Operation, inspection and servicing: The operator of the gate system.

Requirements to be met by qualified and trained specialist staff:

- Knowledge of the general and specific safety and accident-prevention regulations.
- they have knowledge of the relevant electrical regulation,
- Training in the use and care of appropriate safety equipment.
- Adequate instruction and supervision by qualified electricians.
- The ability to recognise hazards that can be caused by electricity.
- Knowledge of the application of the following standards
 - EN 12635 („Doors and gates - Installation and use“),
 - EN 12445 („Safety in use of power operated doors - Requirements“),
 - EN 12445 („Safety in use of power operated doors - Test methods“).
 - EN 13241-1 („Industrial, commercial and garage doors and gates - Part 1: Products without fire resistance or smoke control characteristics“)

Requirements to be met by the operator of the gate system:

- Knowledge and safekeeping of the instruction manual.
- Safe and proper keeping of the inspection logbook.
- Knowledge of general safety and accident-prevention regulations.
- Instruction of all persons who use the door system.
- Ensure that the door system is serviced and maintained periodically by qualified and trained professionals.

Special requirements apply to the following users:

- Children aged eight and above.
- Persons with reduced physical, sensory or mental capabilities.
- Persons with a lack of experience and knowledge.

Ces utilisateurs peuvent uniquement utiliser l'appareil.

Special requirements:

- The users must be supervised.
- The users must have been briefed on how to use the device.
- The users must understand the dangers involved in handling the device.
- Children are not allowed to play with the device.

1.3 Warranty

The product is manufactured in accordance with the guidelines and standards listed in the manufacturer's declaration and in the declaration of conformity. The product left the factory in perfect order with regard to safety.

In the following cases, the manufacturer will accept no liability for damage. The warranty on the product and accessory components becomes void in the event of:

- Failure to observe these operating instructions.
- Incorrect handling and use of the product for anything other than its intended purpose.
- Work being carried out by unqualified personnel.
- Changes or modifications to the product.
- The use of replacement parts that have not been approved or were not manufactured by the manufacturer.

The warranty does not cover batteries, rechargeable batteries, fuses or bulbs.

Further safety instructions are given in the relevant sections of the document.

→ „3. Installation“

→ „5. Care and cleaning“

→ „7. Disassembly“

2. Product information

2.1 Supply package

The Comfort 530 can be supplied in the following versions, as required:



Single wing gate system:



- Comfort 530 - short version
- Comfort 530 L - long version

Double wing gate system:

- Comfort 530 - short version
2x motor unit with short cable (1.5 m)
- Comfort 530 L - long version
2x motor unit with short cable (1.5 m)

The scope of supply is doubled in the case of double wing gate versions.

Item	Gate operator	
1		1x
2		1x

Item	Accessories	530	530L
3		1x	1x
4		1x	-
5		-	1x
6		1x	1x
7		8x	8x
8		4x	4x
9		8x	8x

Item	Accessories	530	530L
10		1x	1x
11		1x	1x
12		1x	1x

2.2 Technical data

Electrical data


Duty cycle	min.	short-term 5
Control voltage	V DC	24
Protection category of motor unit		IP 44
Protection class		II

Mechanical data

Max. push and pull force	N	3,000
Travel speed	mm/s	15-20
Opening time, dependent on gate type	s	15-25


Environmental data

Dimensions of motor unit, Short version



Environmental data

Dimensions of motor unit, Long version



Weight (single wing gate) kg 11.20

Weight (double wing gate) kg 18.00

Sound pressure level dB(A) < 70

Temperature range



°C -20



°C +60

Range of use

Comfort

530

530 L


Hinged gates

- Gate wing width max.	mm	2,500	3,500
- Gate height max.	mm	2,000	2,000
- Gate wing weight max.	kg	350	350
- Gate incline*	% max.	10	10

* with special hinge only

2.3 Example application

2.3 / 1



This is just an example of a gate system and can vary according to the type of gate and the associated equipment. The gate system shown comprises the following components:

- 1 Photocell
- 2 Photocell
- 3 Signal light
- 4 Key switch post (for code button, transponder, ...)
- 5 Wrench
- 6 Main switch (mains isolator switch)
- 7 Electric lock
- 8 Floor bumper
- 9 Mains cable
- 10 Closing edge safety device (CESD/8K2)

Cable cross-sections:

- a 2 x 0.5 mm²
- b 6 x 0,75 mm²
- c 3 x 1.5 mm²
- d 2 x 0.75 mm²

 For the installation and cabling of the gate sensors, control elements and safety equipment, the relevant installation instructions must be observed.

3. Installation

WARNING!

Life-threatening danger due to electric shock!

- It is vital that you disconnect the operator system from the power supply before commencing cabling work. Take measures to ensure that the power supply remains disconnected for the duration of the work.
- Observe the local safety regulations.
- It is imperative that you lay power cables separately from control cables. The control voltage is 24V DC.

NOTICE

Material damage resulting from incorrect installation of the operator!

To avoid installation errors and damage to the gate or operator system, the following installation instructions must be observed at all costs.

- Ensure that the gate is in good mechanical order:
 - The gate can be moved easily.
 - The gate opens and closes properly.
- When installing the operator system, the gate must be in the closed position.
- Only use fixing materials that are suitable for the foundation material in question.

3.1 Preparing for installation

Before commencing installation, the following works must be carried out without fail.

Supply package

- Check that all the parts are present.
- Check that all the necessary accessory parts for your installation situation are present.

Gate system

- Ensure that a suitable mains connection and a mains isolator switch are available for your gate system. The minimum cross-section of the earth cable is $3 \times 1.5 \text{ mm}^2$.
- Ensure that all cables are suitable for outdoor use with respect to UV resistance and cold resistance.
- Ensure that a suitable control unit is available for your gate system.
- Ensure that in the case of double wing gate systems a line from the operator to the controls is available on-site. The minimum cross-section of the cable must be $6 \times 0.75 \text{ mm}^2$.
- Ensure that your gate system has a gate stop in the CLOSE direction.
- Disassemble the gate latches or render them inoperable.
- Ensure that the gate can be easily moved by hand.
- Please note the gate requirements:
→ „2.2 Technical data“

For gate wing widths of 2 metres or more, the use of an electric lock is recommended.

-  When using and installing accessory equipment, observe the corresponding documentation.


NOTICE

Possible malfunction of the operator system!

- Ensure that the following conditions are met:
 - The motor unit must be located in a triangle of forces and should not be parallel to the gate at the OPEN and CLOSED gate positions.
 - The movement stroke must be as large as possible.


Right: Motor unit is in triangle of forces

3.1 / 1



Wrong: Motor unit is parallel to the gate

3.1 / 2



3.2 Installation dimensions

The e value is needed to determine the type of post bracket required.

e Distance between the surface onto which the post bracket is screwed and the pivot of the gate

A Gate pivot

F Surface onto which the post bracket is screwed


Positive e value

The pivot (A) lies behind the surface (F) onto which the post bracket (D) is screwed.

The system can be installed using the standard equipment supplied.


Comfort 530

3.2 / 1



Comfort 530 L

3.2 / 2




Dimension tables

The approximate positions of the gate bracket (C) and the post bracket (D) at the gate can be determined using the dimension tables.

The values given in the table apply to a selected opening angle of 90°.

3.2 / 3



Dimension table, short version – Comfort 530

e	f	x	A	B	B1	1.BR	2.BR
0	f~e	20 – 50	125	130	537	x	-
25	f~e	20 – 50	125	155	536	x	-
50	f~e	20 – 50	125	180	536	x	-
75	f~e	20 – 50	130	205	525	x	-
100	f~e	20 – 50	130	210	525	-	x

- e = 0 – 100 mm
- Maximum door leaf width: 2.5 m
- Maximum door leaf weight: 350 kg

Dimension table, long version – Comfort 530 L


e	f	x	A	B	B1	1.BR	2.BR
100	f~e	20 – 50	200	195	657	x	-
125	f~e	20 – 50	195	220	663	x	-
150	f~e	20 – 50	195	245	652	x	-
175	f~e	20 – 50	180	250	670	-	x
200	f~e	20 – 50	170	275	675	-	x

- e = 100 – 200 mm
- Maximum door leaf width: 3.5 m
- Maximum door leaf weight: 350 kg

3.3 Installation of support brackets

- Use the dimension table to determine the position of the support brackets.


3.3 / 1



The support brackets can alternatively be fixed in place with screw clamps until a successful trial run has been completed.


Concrete and stone pillars

3.3 / 2




The bracket with press fit bushes must be screwed to the post.

3.3 / 3




Metal pillar

3.3 / 4



The bracket with press fit bushes must be screwed to the post.


3.3 / 5



Metal gate

The bracket without press fit bushes must be screwed to the gate.


3.3 / 6



Wooden gate

The bracket without press fit bushes must be screwed to the gate.

3.3 / 7



3.4 Installing the motor unit

CAUTION!

Risk of injury due to shearing forces!

- Using cover caps, seal any unused holes in the post and door brackets.

NOTICE


Material damage resulting from incorrect installation of the gate operator!

If the motor unit screw connection is tight, this can result in faulty operation or irreparable damage to the motor unit. There should still be slight play in both screw joints after assembly. Too much play in the joints will result in noise or knocking when starting up and increase wear in the motor unit.

- Ensure that the fastening screws for connecting the brackets and motor unit are fitted correctly.

Before installation, the motor unit and the connecting components must be greased with the lubricating pad supplied.

3.4 / 1



To ensure that installation is correct, the following tests must be carried out:

- Release the operator.
- „4.2 Emergency operation / Release mechanism“
- ✓ Move the gate slowly by hand into the OPEN and CLOSED end positions.

3.5 Connection to the control unit

To operate the motor unit, it must be connected to a suitable control unit (not included in supply package).

- Follow the instructions in the relevant documentation when connecting the operator to the control unit.

4. Operation


4.1 Hand transmitter

- Follow the instructions in the relevant documentation when operating the hand transmitter.

4.2 Emergency operation / Release mechanism

To ensure that it functions correctly, the operator must be locked in the same position where it has been released.

4.2 / 1




NOTICE

Damage may be caused to property by pressing the cover down incorrectly!

Closing the cover incorrectly may result in it becoming severely deformed. A distorted cover will not close tightly and can result in damage due to the ingress of water.

- Press down on the centre of the cover to close it correctly.

4.2 / 2



5. Care and cleaning

WARNING!

Life-threatening danger due to electric shock!

- It is vital that you disconnect the operator system from the power supply before cleaning. Take measures to ensure that the power supply remains disconnected for the duration of the cleaning operation.

NOTICE

Material damage may result from improper care of drive!

Grease and oil can attack the plastic materials of the drive system and lead to the plastic becoming cracked and fractured. To prevent damage the drive system must only be lubricated or greased according to the instructions.

→ „3.4 Installing the motor unit“

NOTICE

Damage resulting from incorrect operation!

When cleaning the operator system, never use: direct water jets, high pressure cleaners, acids or alkaline solutions.

- Clean the outside of the housing using a damp, soft cloth that does not shed fibres.

If particularly dirty, the housing can be cleaned using a mild detergent.

6. Maintenance

6.1 Maintenance work by the operator

Damage or wear to a door system must only be rectified by qualified and trained professionals.

To ensure fault-free operation, the gate system must be inspected regularly and, if necessary, be repaired. Before starting work on the gate system, the operator system must always be disconnected from the power supply.

- Check once a month that the operator system reverses when the gate touches an obstacle. Place an obstacle in the path of the gate to check this.
- Check all the moving parts of the gate system and gate operator system.
- Check the gate system for signs of damage or wear and tear.
- Move the gate manually to check that the gate travels easily and smoothly.
- Check that the photocell functions properly.
- Check that the closing edge safety device functions properly.
- Check the power supply cable for signs of damage.
For safety reasons, if the power supply cable is damaged it must be replaced by the manufacturer or his customer service department, or by a similarly qualified person.

6.2 Maintenance work by qualified and trained professionals

Power-operated windows, doors and gates must be inspected by qualified and trained professionals whenever necessary, but at least once a year (written inspection records must be kept).

- Test the driving power with a force tester designed for this purpose.
- Replace any damaged or worn parts.

7. Disassembly

WARNING!

Life-threatening danger due to electric shock!

- It is vital that you disconnect the operator system from the power supply before disassembly. Take measures to ensure that the power supply remains disconnected during disassembly.


WARNING!

Possibility of serious injury due to incorrect dismantling!

- Observe all the applicable health and safety regulations.

The system must be dismantled by qualified and trained professionals, following the installation instructions in reverse order.

8. Disposal



Do not dispose of old equipment or batteries with the normal household waste!

- Dispose of old devices at a waste collection centre for electronic waste or via your specialist dealer.
- Dispose of old batteries in a battery recycling container or via a specialist dealer.
- Dispose of the packaging material in the special waste collection containers for paper, cardboard and plastic.

9. Rectifying faults

-  To rectify faults, follow the instructions in the control unit documentation.

10. Appendix

10.1 Declaration for the incorporation of a partly completed machine

(Declaration of Incorporation in line with EC Machinery Directive 2006/42/EC in accordance with Annex II, Part 1 B)

Manufacturer:

Marantec Antriebs und Steuerungstechnik GmbH & Co. KG,
Remser Brook 11, 33428 Marienfeld, Germany

The partly completed machine (product):

Comfort 530 hinged gate operator

Revision status: R01

has been developed, designed and manufactured in accordance with the:

- EU Machinery Directive 2006/42/EC
- EU RoHS Directive 2011/65/EU
- EU Low Voltage Directive 2014/35/EU
- EU Electromagnetic Compatibility Directive 2014/30/EU
- Radio Equipment Directive (RED) 2014/53/EU

Applied and referenced standards and specifications:

- EN ISO 13849-1, PL "c", Cat. 2
Safety of machinery - Safety-related parts of control systems - Part 1: General principles for design
- EN 60335-2-103
Household and similar electrical appliances - Safety - Part 2-103: Particular requirements for drives for gates, doors and windows.
- EN 61000-6-3/2
Electromagnetic compatibility - Emitted interference and immunity

The following requirements of EC Directive 2006/42/EC were complied with:

General principles, No. 1.1.2, 1.1.3, 1.1.5, 1.1.6, 1.2.1, 1.2.2, 1.2.3, 1.2.6, 1.3.1, 1.3.4, 1.3.7, 1.3.8, 1.3.9, 1.4.1, 1.4.3, 1.5.1, 1.5.4, 1.5.6, 1.5.8, 1.5.14, 1.7

Furthermore, we declare that the special technical documentation for this partly completed machine was prepared in accordance with Annex VII Part B and we undertake to supply these documents, in electronic form, to the national authorities in response to a duly reasoned request.

This partly completed machine is intended only for installation in a door system, in order to create a complete machine pursuant to Machinery Directive 2006/42/EC. The door system may not be set in operation until it has been ascertained that the complete system complies with the requirements of the above-mentioned EC directives.

This declaration shall no longer be valid if changes are made to the product without our authorisation.

Authorised agent for the preparation of the technical documentation:

Marantec Antriebs- und Steuerungstechnik GmbH & Co. KG,
Remser Brook 11, 33428 Marienfeld, Germany
Fon +49 (5247) 705-0



Marienfeld, 1 February 2016

M. Hörmann
Director





Identification plate, motor unit 1

Type A _____

Rev(B) _____

Art. No.(C) _____

Prod. No. (GB)

Identification plate, motor unit 2 (only double wing)

Type A _____

Rev(B)

Art. No.(C) _____

Prod. No. (GB) _____

The diagram illustrates a product label layout. On the left is a large gray rectangle representing the main label area. To its right are three horizontal gray bars of varying lengths, with the top bar labeled 'A' and the middle bar labeled 'B'. Below these bars is a large 'CE' mark. To the right of the 'CE' mark is a barcode, with a small gray box labeled 'D' positioned directly beneath it. Above the barcode is a horizontal gray bar with a slash '/' and the letter 'C' to its right.

